

## Warranty Information

Grace Industries, Inc. warrants the GLOW BATON® to be free from defects in workmanship and materials for a period of one year from the date of purchase. This warranty is valid only when the returned unit is accompanied by a sales slip or other proof of purchase that states the date and location of purchase. Grace Industries, Inc. will not repair or replace any merchandise under warranty which has been damaged because of accident, misuse or abuse of the GLOW BATON® while in possession or control of the consumer. This warranty is void if any attempt to repair or replace parts was made or attempted by other than qualified Grace Industries, Inc. personnel. This warranty is void if any of the sealed compartments are opened or tampered with. Send all returned merchandise, prepaid and accompanied by proof of purchase to: Grace Industries, Inc., Repair Division, 305 Bend Hill Road, Fredonia, PA 16124. Grace Industries, Inc. shall not be liable for any direct, incidental or other consequential loss or damage arising out of the failure of the device to operate.

The sole and exclusive remedy under all guarantees or warranties, expressed or implied, is strictly limited to repair or replacement as herein provided. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE HEREBY LIMITED IN DURATION TO A PERIOD ENDING ONE (1) YEAR FROM THE DATE OF PURCHASE. The warranty and liability set forth in the prior paragraphs are in lieu of all other warranties, expressed or implied, in law or in fact, including implied warranties of merchantability and fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

The information contained in this booklet is believed to be accurate and reliable. Grace Industries, Inc. provides this information as a guide only.

GLOW BATON® technical assistance is available by contacting Grace Industries, Inc. at 800-969-6933.

For training purposes a copy of this information is available by contacting Grace Industries, Inc.

# GLOW BATON®

Models 100, 400 & 500

Glow, Flash, Strobe

Heavy Duty



**GRACE**  
INDUSTRIES, INC.  
*Solutions for Life Safety*


305 Bend Hill Road, Fredonia PA 16124  
724.962.9231 • www.graceindustries.com

© Grace Industries, Inc.

Printed in U.S.A.


GLOWBATON HD 100 400 500 UI 0514

## GLOW BATON® Models 100, 400 & 500



Model 100 shown here

ON/OFF Button  
(see operating instructions on back page)



Lanyard

End Cap



Unscrew Glow Baton's End Cap to Replace Batteries  
Requires Two (2) C-Cell Alkaline Batteries

### Introduction

Glow Baton eliminates hazards caused by standard road flares.

They are built to perform well under most environmental conditions.

This versatile signaling device is constructed of rugged industrial grade plastic. Glow Baton is waterproof and will provide years of use with reasonable care.

### Specifications

**Material:** Industrial grade plastic components

**Size:** 16" long x 1<sup>5</sup>/<sub>8</sub>" diameter

**Weight:** 12.7 oz with batteries

**Power:** Two (2) C-cell alkaline batteries. Duracell or ProCell recommended

**Battery Life:** 72 hours Glow; 144 hours in Flashing or Strobe modes

# **GLOW BATON**<sup>®</sup> Model 100 - Red LEDs

## **Operating Instructions**

Press button once to turn Glow Baton **ON**; Press again to turn **OFF**.

These instructions describe how to select Steady Glow, Flashing, or a Strobe pattern.

1. **Steady Glow:** Press and quickly release button to turn Glow Baton **ON** for **Steady Glow**.
2. **Flashing:** Press and hold button (approx. 4 seconds) until unit changes from steady glow to **Flashing** pattern.
3. **Strobe:** Press and hold button (approx. 6 seconds) until unit changes from steady glow, to flashing and then to **Strobe** pattern.

# **GLOW BATON**<sup>®</sup> Model 400 - Red and Green LEDs

## **Operating Instructions**

Each time the button is pressed, Glow Baton will go to the next color.

Press button once for **Red** color, press again for **Green**, and press again to turn Glow Baton **OFF**.

The following instructions describe how to select Steady Glow, Flashing, or a Strobe pattern within each of the two (2) colors.

1. **Steady Glow:** Press and quickly release button to turn Glow Baton **ON** for **Steady Glow**.
2. **Flashing:** Press and hold button (approx. 4 seconds) until unit changes from steady glow to **Flashing** pattern.
3. **Strobe:** Press and hold button (approx. 6 seconds) until unit changes from steady glow, to flashing and then to **Strobe** pattern.

# **GLOW BATON**<sup>®</sup> Model 500 - Red, Green and Blue LEDs

## **Operating Instructions**

Each time the button is pressed, Glow Baton will go to the next color.

Press button once for **Red** color, press again for **Green**, press again for **Blue**, and press again to turn Glow Baton **OFF**.

The following instructions describe how to select Steady Glow, Flashing, or a Strobe pattern within each of the three (3) colors.

1. **Steady Glow:** Press and quickly release button to turn Glow Baton **ON** for **Steady Glow**.
2. **Flashing:** Press and hold button (approx. 4 seconds) until unit changes from steady glow to **Flashing** pattern.
3. **Strobe:** Press and hold button (approx. 6 seconds) until unit changes from steady glow, to flashing and then to **Strobe** pattern.